

PROFESSIONAL
SERIES

VALOR[®]

AMPLIFIED - EXTRA LOUD
Speaker / Microphone

USER GUIDE



sonim[®]

WE SERVE THE PEOPLE
WHO SERVE US

USER GUIDE

Welcome! Here is a quick guide to using your brand new speaker / microphone...

Step 1: Charge up the battery using the included wall charger.
It should not take more than 2 hours maximum.


NOTE:

- RED light = Low Battery
- ORANGE Light = Charging
- Light turns off when complete.

That big button on the front and button on the side are both PTT buttons! They have the same function but we put two there for ease of use. PTT = Push To Talk.

TO HAVE A 2-WAY RADIO STYLE "CALL":

When you are in the PTT application on your phone, highlight the contact person or group that you want to talk to, and now you have the option to first send them a Notification that you want to talk, **or** just start talking.

1. To send a Notification, Short-Press the PTT and quickly release it. Now they know you want to talk.
2. To converse in 2-way radio format, simply press the PTT while talking (also called having the Floor), and release to listen.
3. To end the conversation, simply stop talking, or you can "force end" by hanging up as you would a phone call using the  button on the phone.

TO MAKE OR RECEIVE A PHONE CALL:

1. To accept an incoming call, short press the PTT button. You will hear a tone when the call is accepted.
2. To end the call, simply press the PTT button again.
3. To reject an incoming call, Long-Press the PTT button while ringing and it will route to your voicemail.
4. NOTE: On some models other options exist such as Last Number Redial.
To see if your device has this function, Short-Press the PTT Button **twice**. A tone will notify you of the action.

VALOR[®]

Cellular PTT Products



made in
usa

earpiece options



SHADOW-V.
Locking cam.

SHADOW-PRO-V.
Armature speaker.
Shorter tube.
Locking cam.



**LOCKING
CAM!**

Patent pending

Side PTT

Front Facing
PTT Button &
Speaker

Earpiece
Port 2
Micro USB
Charger Port

Earpiece Port 1

Microphone

Rubber
Overmold



See back for CAM-LOCK
cable instructions & compatibility



Overmolded
Rubber available
in BLACK or
SAFETY ORANGE

CAM-LOCK Cable Instructions for XP5, XP6 & XP7 phones



Proper alignment of camlock connector cable with headset port, for proper insertion into camlock groove in headset jack.



1/4 turn rotation to the left (counterclockwise) once camlock connector is properly inserted into headset jack.



Placement of camlock connector sitting properly under the steel plate.

www.KleinElectronics.com
a Klein Electronics, Inc. brand

Patent Pending. All trademarks and service marks
are the property of their respective owners.